

Short Circuit Current Ik

Fronius International GmbH

declares the following values for the initial short-circuit alternating current $I_k{}^{\prime\prime}$ and the maximum switch current factor k_{imax}

	I _k ''	k _{imax}
Fronius Symo 20.0-3-M	32 A (1.10 I _N *)	0.33
Fronius Symo 17.5-3-M	32 A (1.26 I _N *)	0.33
Fronius Symo 15.0-3-M	32 A (1.47 I _N *)	0.33
Fronius Symo 12.5-3-M	20 A (1.10 I _N *)	0.33
Fronius Symo 10.0-3-M	20 A (1.38 I _N *)	0.33
*I _N at 230V		

The steady state short-circuit current I_k is dependent on the country setup/configuration:

 I_k = 0A in case Voltage Fault Ride Through is off or Zero Current Mode

 I_k = max. I_k " in case current support is activated during Voltage Fault Ride Through

Peak current during first halfwave i_P is also defined by I_k ":

i_P = 1.42 I_k"

Fronius International GmbH

Business Unit Solar Energy Froniusplatz 1 4600 Wels

Philipp Rechberger Head of System Technology